

Anzio Mounting Instructions

1. Decide on the height that you want the fire to be mounted from the floor
2. Take the angled bracket that came with the surround and place it on the wall.
3. The height from the bottom of the fire to the bottom the bracket is 703mm.
4. Add the desired height and the distance from the bracket to the bottom of the fire to get the correct height to fix the bracket to the wall.
5. Ensure that the bracket is in the correct orientation when fitting the fire.
6. Screw one side of the bracket to the wall and ensure that it is level by pivoting the bracket and using a spirit level, before screwing the other side.
7. Bring the power cable through the cut out for the optimyst tray.
8. Plug the optimyst tray in and then slide the tray into the cut out.
9. Carefully lift the surround from the base and supporting the top, lift it over the bracket so that when it is brought back down it hooks onto the bracket.
10. Job done. Enjoy your new fireplace!